



# Connecting a LED on a Niko™ pushbutton - Aansluiting led op een Niko™ drukknop - Connexion d'une LED à un poussoir Niko™ - Einen Niko™-Druckknopf mit einer LED verbinden - Conectar pulsadores Niko™

Slide the blue (type VMBLDN) or amber (type VMBLDAN) LED into the slot of the pushbutton

Schuif de blauwe led type VMBLDN of amber led type VMBLDAN in de sleuf van de drukknop - Insérez la LED bleue (VMBLDN) ou ambrée (VMBLDAN) dans la fente prévue à cet effet - Befestigen Sie die blaue LED (Typ VMBLDB) oder die amberfarbige LED (Typ VMBLDAB) am Druckknopf - Introduzca el LED azul (VMBLDN) o el LED naranja (VMBLDAN) en la ranura del pulsador.




## Connection pushbutton 1

Drukknopaansluiting 1  
connexion poussoir 1  
Anschlusskabel Druckknopf 1  
conexión pulsador 1


## Connection pushbutton 2

Drukknopaansluiting 2  
connexion poussoir 2  
Anschlusskabel Druckknopf 2  
conexión pulsador 2



## Common connection

Gemeenschappelijke  
connexion COM  
Gemeinsames Anschlusskabel  
conexión COM



Black - zwart -  
noir - Schwarze  
- negro

White - Wit -  
Blanc - Weiße -  
Blanco